

Talc Free Matte Eye Shadow	Formulation Number: 100-070, UES-0017
-----------------------------------	---------------------------------------

Phase	Trade Name	INCI Name	Function	Supplier	%	
A	VLS CS-15	Mica (and) Lecithin	Filler	Miyoshi America, Inc.	41.55%	
	MiyONAT VAA RED	Iron Oxides (and) Sodium Myristoyl Glutamate (and) Aluminum Hydroxide	Pigment		2.40%	
	MiyONAT VAA YELLOW				3.60%	
	MiyONAT VAA BLACK				1.00%	
	MiyONAT VAA WHITE	Titanium Dioxide (and) Sodium Myristoyl Glutamate (and) Aluminum Hydroxide			4.00%	
	MiyofEEL SX-L	Mica (and) Silica (and) Lecithin	Texture Modifier		Miyoshi America, Inc.	15.00%
	PURITY® 21C	Zea Mays (Corn) Starch	Texture Modifier		Nouryon	10.00%
	Kaolin 2000C	Kaolin	Filler		KaMin Solutions	5.00%
	Magnesium Stearate	Magnesium Stearate	Dry Binder		MakingCosmetics Inc.	3.00%
	Ronafclair® ESQ	Bismuth Oxychloride	Texture Modifier		EMD Performance Materials / Rona	9.00%
B	PELEMOL® SR-350	Coco-Caprylate/Caprate (and) Dimer Diilinoleyl Dimer Diilinoleate	Emollient	Phoenix Chemical, Inc.	1.75%	
	PELEMOL® GTIS	Triisostearin			1.25%	
	PELEMOL® D5R-V	Propanediol Dicaprylate/Caprate (and) Diisostearyl Malate			1.25%	
	Bronidox® 1160	Phenoxyethanol	Preservative	BASF Care Creations	1.00%	
	Bioderma SX-19	Shea Butter	Emollient	Miyoshi America, Inc.	0.20%	
				Total:	100.00%	

- Procedure**
- 1 Weigh Phase A into a blender and blend on high for 1½ minutes.
 - 2 Add Phase B to a beaker, begin mixing with a propeller mixer @ 300 to 400 rpm. Turn on heat and begin heating to 50°C.
 - 3 Once all components are dissolved and homogeneous, (about 10 minutes) add Phase B to Phase A.
 - 4 Blend for 1 minute on low speed. Scrape the sides and blend for an additional 30 seconds. Press a cake, check for oil spots and continue blending and additional 30 seconds if necessary.
 - 5 Press into desired eye shadow packaging.